



Einhell

POWER X-CHANGE

Portable Pressure Washer

TE-HP 18/10 Li D-Solo

Item No.: 4140165

Ident No.: 21015

Bar Code: 4006825691320

The cordless pressure washer TE-HP 18/10 Li D-Solo offers cordless flexibility for cleaning or irrigation in the garden or on the go. As part of the Power X-Change battery platform, all system batteries can be used. With two pressure settings (3 bar for gentle cleaning, 10 bar for thorough cleaning) and a flow rate of 140 litres/hour, the low-pressure cleaner delivers thorough results. Two separate tanks (7.5 litres of water, 0.75 litres of detergent), as well as a splash-proof battery compartment, ensure convenience. The set includes a 2.6 m spiral hose, a 3-in-1 nozzle, a cleaning brush and a 5-m suction hose with a water filter. The accessories can be conveniently stored in the built-in holder. Battery and charger not included.

Features & Benefits

- A member of the Power X-Change family; 1 x 18 V battery required
- Fast, cordless cleaning or watering
- Longer running time without cable thanks to the interchangeable battery system
- 2 pressure settings: gentle care or thorough cleaning
- Two separate, removable tanks for water and cleaning agent
- Splash-proof battery compartment
- Built-in holder for storing accessories or a spare battery
- Incl. a 2.6-m spiral hose with multi-purpose nozzle
- 3-in-1 nozzle for jet, wide spray or watering
- Incl. 5-metre suction hose for water extraction from buckets, ponds, etc.
- Incl. water filter to protect the pump
- Incl. cleaning brush for hard-to-reach areas
- Battery and charger not included (available separately)



Technical Data

- Clean water tank capacity	7.5 l
- Flow rate	140 l/h
- Max. pressure stage 1	3 bar
- Max. pressure stage 2	10 bar
- Max. suction height	1.5 m
- Max. water temperature	45 °C
- Motor voltage	18 V
- Pressure hose length	2.6 m
- Suction hose length	5 m
- Volume of detergent container	0.75 l

Logistic Data

- Product weight	4.11 kg
- Gross weight	5.74 kg
- Dimensions single packaging	287 mm x 270 mm x 490 mm
- Pieces per export carton	1 pcs
- Gross weight of export carton	5.74 kg
- Dimensions export carton	285 mm x 270 mm x 490 mm
- Container quantities (20"/40"/40"HC)	743 pcs 1538 pcs 1803 pcs



Available as special accessories



Power X-Charger 0,8A
Charger
Item No.: 4512165
Bar Code: 4006825685084
Einhell Accessory



PXC 18V 2,0Ah
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



PXC 18V 5,2Ah
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4-6Ah MULTI
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



PXC 18V 4,0Ah C01
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC+ 18V 3,0Ah
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Twincharger 4A
Charger
Item No.: 4512161
Bar Code: 4006825680638
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



18V 2,5Ah PXC Starter Kit - ZG
PXC-Starter-Kit
Item No.: 4512170
Bar Code: 4006825686029
Einhell Accessory

Battery-Running-Times

Battery Capacity	2.0 Ah	2.5 Ah	3.0 Ah	4.0 Ah	5.2 Ah	6.0 Ah	8.0 Ah
Performance	26 min	32 min	39 min	52 min	69 min	78 min	105 min

Max. running time per battery charge: ECO mode

ECO mode: Longer battery life with reduced performance.

Performance	15 min	18 min	23 min	30 min	38 min	46 min	60 min
-------------	--------	--------	--------	--------	--------	--------	--------

Max. running time per battery charge: BOOST mode

BOOST mode: Maximum performance with reduced battery life.